

EMERGENCY ACTION CARD

ThunderBank · Production Crew

LIGHTNIN 24/7 EMERGENCY · PRIORITY ORDER
678-472-5682 · 470-244-3905 · 877-433-0313

voicemail or text if no answer

IF YOU SEE / HEAR / SMELL...

Smoke, flame, burning-plastic smell	1. EMERGENCY STOP · 2. CALL 911 · 3. Call Lightnin · 4. Evacuate 50+ ft · Do NOT open door
Hissing, popping, unusual sound	EMERGENCY STOP · CALL 911 to be safe · then call Lightnin. <i>Skip the action only if you can clearly identify the sound as routine: truck airbags, tires, inverter clicks, breaker trips.</i>
Melting / scorching at a camlock or 120V Edison receptacle	Likely bad cable or overloaded cable specs · Call Lightnin · verify no other problems · don't reuse cable or plug without maintenance
Small flame / arcing at exterior camlock or Edison (no fire inside box)	EMERGENCY STOP · if safe, use ABC extinguisher (rear-left bumper) · if doesn't go out, CALL 911 then call Lightnin · don't risk safety
VRM alert: panel temp $\geq 150^{\circ}\text{F}$	EMERGENCY STOP · call Lightnin · inspect exterior and VRM data
Electric shock / arcing	Don't touch victim · EMERGENCY STOP · CALL 911 then call Lightnin
Water leaking into box	EMERGENCY STOP · disconnect shore if safe · call Lightnin
Truck fuel spill	Engine OFF · Alternator OFF · EMERGENCY STOP · no ignition · call Lightnin
Truck engine fire or collision	Engine OFF (if safe) · Alternator OFF · EMERGENCY STOP · CALL 911 then call Lightnin

EMERGENCY STOP // Do-Not List

EMERGENCY STOP BUTTON

Where: Rear right corner of truck box, right of AC output panel. Red/white decal with arrow.

How: Press firmly. Button locks in place.

What it does: Cuts off all inverters · disconnects AC In/Out · isolates batteries (still charged).

Reset: Only after Lightnin clears the unit.

TRUCK ALTERNATOR (3RD CHARGE PATH)

In any emergency: shut off the truck engine, then switch the alternator **OFF**.

Switch location: In the cab, **left of the steering wheel**.

Indicator illuminated = alternator fault. Leave switch OFF until Lightnin clears it.

DO NOT

- ✗ Open the personnel door during a fire or 150°F+ alert
- ✗ Touch camlock connections when energized
- ✗ Try to extinguish a battery fire yourself
- ✗ Spray water on energized AC panels
- ✗ Reset **EMERGENCY STOP** until Lightnin clears the unit
- ✗ Turn alternator on after fault light illuminates

EVACUATION SEQUENCE

1. Hit **EMERGENCY STOP**
2. **Engine OFF** · Alternator OFF (left of steering wheel)
3. Move personnel 50+ ft from the truck
4. **CALL 911** if any fire / smoke / thermal sign
5. Call Lightnin: **678-472-5682** / 470-244-3905 / 877-433-0313
6. Designate briefer for Fire Dept.; hand them the Fire Dept. Card